



***OBSOLETE BLOWER MODEL 4000-16/47***

The following list of parts, headed by the blower model number and series, are the recommended spare parts for a normal overhaul. This list includes all bearings, seals, and miscellaneous lock and screws that are not normally reusable after disassembly.

Prices quoted are Ex Works, Springfield, MO USA. Minimum order \$50.

***REPAIR KIT 27305***

<u>Item Number</u>	<u>Description</u>	<u>Part Number</u>	<u>Quantity</u>
0	Gear Lock Plate	40325	2
9	Ball Bearing	11249	3
10	Ball Bearing	11783	2
12	Lip Seal	11443	4
13	Lip Seal	11600	1
16	Timing Gear Shim	40357	1
24	Gear Key	11150	2
28	Gasket	22258	2
29	Cap Screw	90293-100	1
30	Cap Screw	92241-050	4
36	Gear Washer	5872	2
61	Lock Plate	6038	4
65	Lock Plate	11739	2
69	Cap Screw	90293-175	1

The following part(s) are listed for reference only and are not a part of the repair kit:

8	Gear Assembly	29604*	1
39	Port Gasket	26530 (4006)	2
39	Port Gasket	7932 (4009)	2
39	Port Gasket	8923 (4012)	2
39	Port Gasket	8923 (4014)	2

\*item 8, P/N 60169 ground gears replaced by P/N 29604 shaved gears - 5/26/05