



MODELS 4500 EQUALIZER[®] DF[™]

The following list are recommended spare parts for a normal overhaul.
This list includes all bearings, seals, and miscellaneous locks and screws
that are not normally reusable after disassembly.

Prices quoted are Ex Works, Springfield, MO USA. Minimum order \$50.

REPAIR KIT 46172

<u>Item Number</u>	<u>Description</u>	<u>Part Number</u>	<u>Quantity</u>
0	Locking Plate	61000	2
0	Timing Shim	61001	1
9	Ball Bearing	61004	2
10	Ball Bearing	30410-2308	2
12	Lip Seal	46023	4
13	Lip Seal	46024	1
24	Gear Key	61012	2
58	Seal Ring	46022	4

The following parts are listed for reference only and are not a part of the repair kit:

8	Gear Assembly	61106	1
39	Port Gasket (4504)	46168	2
39	Port Gasket (4506)	46169	2
39	Port Gasket (4509)	46710	2
39	Port Gasket (4512)	46171	2