



**MODELS 4600 EQUALIZER<sup>®</sup> RM, 4700 ACOUSTICAIR<sup>™</sup>**

The following list are recommended spare parts for a normal overhaul.  
 This list includes all bearings, seals, and miscellaneous locks and screws  
 that are not normally reusable after disassembly.

Prices quoted are Ex Works, Springfield, MO USA. Minimum order \$50.

**REPAIR KIT 46044**

<u>Item Number</u>	<u>Description</u>	<u>Part Number</u>	<u>Quantity</u>
0	Locking Plate	61000	2
0	Timing Shim	61001	1
9	Ball Bearing	61004	2
10	Roller Bearing	30410-308	1
12	Lip Seal	46023	4
13	Lip Seal	46024	1
24	Gear Key	61012	2
50	Roller Bearing	30410-2308	1
58	Seal Ring	46022	4

---

The following parts are listed for reference only and are not a part of the repair kit:

8	Gear Assembly	61106 (4600)	1
8	Gear Assembly	46069 (4700)	1
39	Port Gasket (4609 & 4609D)	32099-040	2
39	Port Gasket (4612D)	32099-060	2