



***STANDARD BOOSTER MODEL 1200-35/37***

The following list of parts, headed by the booster model number and series, are the recommended spare parts for a normal overhaul. This list includes all bearings, seals, and miscellaneous lock and screws that are not normally reusable after disassembly.

Prices quoted are Ex Works, Springfield, MO USA. Minimum order \$50.

***REPAIR KIT 14533***

<u>Item Number</u>	<u>Description</u>	<u>Part Number</u>	<u>Quantity</u>
	Ball Bearing	8522	2
	Cap Screw	22851	2
	Ball Bearing	92141	2
9	Ball Bearing	14031	4
12	Lip Seal	14229	4
16	Timing Gear Shim	14017	1
24	Gear Key	91788	2
36	Lockwasher	91786	4
50	Roller Bearing	32386-22220	1
76	Seal Stator	14442-1	1
76	Seal Rotor	14445	1
88	O-Ring	29361-153	1
140	O-Ring	29361-252	1
176	O-Ring	91791	2
280	Teflon Washer	23644	20
302	O-Ring	91790	2
305	O-Ring	29361-029	4
314	O-Ring	29361-167	2
325	O-Ring	29361-138	2

The following part is listed for reference only and is not a part of the repair kit:

8	Gear Assembly	14012	1
---	---------------	-------	---

Item 50 changed from 14032 in Aug. 2007.

Aug-07